MultiPASS C635
MultiPASS C3500
MultiPASS C5500

PARTS CATALOG

Canon

FIGURE 1 PACKAGE CONTENTS



NUM.	PART #	DESCRIPTION
1-1	WT3-5021-000	POWER SUPPLY CORD, 120V
2	HB1-3286-000	TRAY, SUPPORT DOCUMENT
3	HB1-2723-000	TRAY, EXIT DOCUMENT
4	HH2-2824-000	MODULAR CORD, 2P
5	HB1-2717-000	TRAY, PAPER EXTENSION
6	NPN	BJ CARTRIDGE CONTAINER
7	QB1-2213-000	LID, CONTAINER
8	NPN	BCI-21 BLACK BJ INK CARTRIDGE
9	NPN	BC-21E COLOR BJ CARTRIDGE

FIGURE 2 UPPER COVER & PRINTER COVER



NUM.	PART #	DESCRIPTION
2-1	HB1-2886-000	GUIDE, DOCUMENT, LEFT
2	HB1-2885-000	GUIDE, DOCUMENT, RIGHT
3	HB1-2884-000	COVER, PRINTER
4	HB1-2883-000	SLIDER, RACK (2)
5	HS5-2130-000	SPRING, SLIDER
6	HS5-0238-000	GEAR, Z16
7	HB1-3287-000	SHEET, CARTRIDGE
8	XA9-0476-000	SCREW, TP, M3X8
9	HB1-2701-080	COVER, UPPER

FIGURE 3 SCANNER & OPERATION PANEL



NUM.	PART #	DESCRIPTION
3-1	NPN	OPERATION PANEL & ADF UPPER
2	NPN	ADF LOWER ASS'Y
3	XB2-7300-607	SCREW, M3X6 (2)
4	HB1-2888-000	GUIDE, CABLE
5	HH7-2172-000	SPEAKER
6	HB1-2867-000	STOPPER, OPERATION PANEL

FIGURE 4 MultiPASS C3500 SCNT BOARD & NCU BOARD



NUM.	PART #	DESCRIPTION
4-1	HB1-2781-000	COVER, NCU
2	XB1-2300-607	SCREW, BH3X6 (S) (5)
3	HH2-2522-000	WIRE, GROUNDING
4	HG1-4268-040	NCU BOARD ASS'Y
5	HG5-1588-000	SCNT BOARD ASS'Y
6	HB1-2721-050	PLATE, CIRCUIT BOARD BASE
7	HH2-2834-000	CABLE, FLAT, 21P
8	HH2-2833-000	CABLE, FLAT, 15P
9	XB6-7300-607	SCREW, TP, M3X6 (2)
10	HH2-2730-000	CABLE W/CONNECTOR, 5P
11	HH2-2728-020	CABLE, FLAT

FIGURE 5 MultiPASS C5500 SCNT BOARD & NCU BOARD



NUM.	PART #	DESCRIPTION
5-1	HB1-2781-000	COVER, NCU
2	XB1-2300-607	SCREW, BH3X6 (S) (5)
3	HH2-2522-000	WIRE, GROUNDING
4	HG1-4268-040	NCU BOARD ASS'Y
5	HG5-1546-000	SCNT BOARD ASS'Y
6	HB1-2721-050	PLATE, CIRCUIT BOARD BASE
7	HH2-2834-000	CABLE, FLAT, 21P
8	HH2-2833-000	CABLE, FLAT, 15P
9	XB6-7300-607	SCREW, TP, M3X6 (2)
10	HH2-2730-000	CABLE W/CONNECTOR, 5P
11	HH2-2728-020	CABLE, FLAT

FIGURE 6 MAIN FRAME ASS'Y



NUM.	PART #	DESCRIPTION
6-1	NPN	PRINT & ASF ASS'Y
2	XB4-7300-807	SCREW, TAP TIGHT, BINDING HEAD (2)
3	HH3-5325-000	POWER SUPPLY UNIT
4	HB1-2722-040	GUIDE, PAPER, MANUAL FEED

FIGURE 7 OPERATION PANEL & ADF, UPPER



NUM.	PART #	DESCRIPTION
7-1	HB1-2713-000	ABSORBER, WASTE INK B
2	HB1-2712-000	ABSORBER, WASTE INK A
3	HB1-2714-000	TRAY, RECORDING PAPER
4	HF5-0279-030	MAIN FRAME ASS'Y
5	QB1-0507-000	FOOT, PRINTER
6	HB1-2715-000	PLATE, PAPER SUPPORT (LEFT)
7	HB1-2716-000	PLATE, PAPER SUPPORT (RIGHT)
8	QB1-3143-000	SHEET, SPACER (2)

FIGURE 8 MultiPASS C3500 OPERATION PANEL ASS'Y & ADF UPPER



NUM.	PART #	DESCRIPTION
8-1	HB1-3329-000	SHEET, OPERATION PANEL
2	HG5-1594-000	OPERATION PANEL ASS'Y
3	HB1-2725-000	FACE PLATE, ONE-TOUCH DIAL
4	HH2-2755-000	CABLE, FLAT
5	NPN	SEE PAGE 11
6	XB4-7300-807	SCREW, TAP TIGHT, BINDING HEAD (2)
7	XB1-2300-607	SCREW, BH3X6(S)

FIGURE 9 MultiPASS C5500 OPERATION PANEL ASS'Y & ADF UPPER



NUM.	PART #	DESCRIPTION
9-1	HB1-3292-000	SHEET, OPERATION PANEL
2	HG5-1556-000	OPERATION PANEL ASS'Y
3	HB1-2725-000	FACE PLATE, ONE-TOUCH DIAL
4	HH2-2755-000	FLAT CABLE (SCNT-OPCNT)
5	NPN	SEE PAGE 11
6	XB4-7300-807	SCREW, TAP TIGHT, BINDING HEAD (2)
7	XB1-2300-607	SCREW, BH3X6(S)

FIGURE 10 MultiPASS C3500 ADF, UPPER



NUM.	PART #	DESCRIPTION
10-1	HB1-2874-000	LEVER, SWITCHING
2	XA9-0476-000	SCREW, TP M3X8
3	XB4-7300-807	SCREW, TAP TIGHT, BINDING HEAD (3)
4	HB1-2866-000	PLATE, PRESSURE (2)
5	HS5-6042-000	ROLLER, DELIVERY, 2
6	HB1-2863-000	STOPPER, DOCUMENT
7	HB1-2865-000	SHAFT, BACK UP ROLLER (2)
8	HS5-2131-000	SPRING
9	HG5-1239-000	SEPARATION GUIDE ASS'Y
10	HB1-2862-000	ARM, DETECTION (DS)
11	HB1-2864-000	ROLLER, BACK UP
12	HS5-6023-030	ROLLER, BACK UP
13	HB1-2861-000	ARM, DETECTION (DES)
14	HG5-1245-000	DOCUMENT EDGE SENSOR ASS'Y
15	HH2-2747-000	CABLE W/CONNECTOR, 3P
16	HH2-2746-000	CABLE W/CONNECTOR, 3P
17	HG5-1244-000	DOCUMENT SENSOR ASS'Y
18	HB1-2860-020	COVER, ADF, UPPER
19	HB1-2875-000	SHEET, DOCUMENT STOP
20	HB1-1784-000	BRUSH, STATIC DISCHARGE
21	HS5-2129-000	SPRING, WHITE SHEET (3)
22	HF5-0399-000	WHITE SHEET UNIT
23	HH2-2810-000	WIRE, GROUNDING

FIGURE 11 MultiPASS C5500 ADF, UPPER



NUM.	PART #	DESCRIPTION
11-1	HB1-2874-000	LEVER, SWITCHING
2	XA9-0476-000	SCREW, TP, M3X8
3	XB4-7300-807	SCREW, TAP TIGHT, BINDING HEAD (3)
4	HB1-2866-000	PLATE, PRESSURE (2)
5	HS5-6042-000	ROLLER, DELIVERY, 2
6	HB1-2863-000	STOPPER, DOCUMENT
7	HB1-2865-000	SHAFT, BACK UP ROLLER (2)
8	HS5-2131-000	SPRING
9	HG5-1239-000	SEPARATION GUIDE ASS'Y
10	HB1-2862-000	ARM, DETECTION (DS)
11	HB1-2864-000	ROLLER, BACK UP
12	HS5-6023-030	ROLLER, BACK UP
13	HB1-2861-000	ARM, DETECTION (DES)
14	HG5-1245-000	DOCUMENT EDGE SENSOR ASS'Y
15	HH2-2747-000	CABLE W/CONNECTOR, 3P
16	HH2-2746-000	CABLE W/CONNECTOR, 3P
17	HG5-1244-000	DOCUMENT SENSOR ASS'Y
18	HB1-2860-020	COVER, ADF, UPPER
19	HB1-2875-000	SHEET, DOCUMENT STOP
20	HB1-1784-000	BRUSH, STATIC DISCHARGE
21	HS5-2129-000	SPRING, WHITE SHEET (3)
22	HF5-0399-000	WHITE SHEET UNIT
23	HB1-2897-000	SHEET, LIGHT SHIELD
24	HH2-2810-000	WIRE, GROUNDING

FIGURE 12 SEPARATION GUIDE ASS'Y



NUM.	PART #	DESCRIPTION
12-1	HS5-2079-000	SPRING, SEPARATION GUIDE
2	HB1-2873-030	HOLDER, SEPARATION GUIDE
3	HB1-2871-030	PLATE, PRESSURE
4	HB1-2872-000	PAD, SEPARATION
5	HB1-2898-000	SHEET, SEPARATION
6	HB1-2895-000	HOLDER, SEPARATION

FIGURE 13 ADF, LOWER (1)



NUM.	PART #	DESCRIPTION
13-1	HB1-2891-020	COVER, ADF LOWER
2	HB1-2881-000	SHAFT, SEPARATION ROLLER
3	HS5-0237-000	GEAR, 32T
4	HS5-2027-000	SPRING, CLUTCH
5	HB1-1779-000	SPACER
6	XB4-7300-807	SCREW, TAP TIGHT, BINDING HEAD (2)
7	HF5-0305-000	PANEL HOLDER UNIT (2)
8	HB1-3034-000	ROLLER, SEPARATION
9	HS1-1063-000	BUSHING
10	HS5-0231-000	GEAR, 55T/19T
11	HS5-0230-000	GEAR, 44T/57T
12	HS5-0232-000	GEAR, 56T
13	HB1-2882-000	PLATE, GROUNDING
14	XB1-2300-407	SCREW, BH3X4 (S)
15	HS5-0236-000	GEAR, 36T/24T
16	HS5-0233-000	GEAR, 34T
17	HS5-0234-000	GEAR, 42T

FIGURE 14 MultiPASS C3500 ADF, LOWER



NUM.	PART #	DESCRIPTION
14-1	HB1-3328-000	PLATE, GROUNDING
2	HH2-2831-000	CABLE W/CONNECTOR, 7P
3	HG5-1592-000	CONNECT SENSOR ASS'Y
4	HB1-2890-000	FRAME, ADF, LOWER
5	HS5-0235-000	GEAR, 19T
6	HB1-2878-000	ROLLER, DOCUMENT FEED
7	XD2-1100-402	RETAINING RING (E-TYPE)
8	HS1-1063-000	BUSHING
9	HB1-3289-000	ROLLER, DOCUMENT EJECT
10	HH7-2331-000	MOTOR, DOCUMENT FEED
11	XB4-7300-807	SCREW, TAP TIGHT, BINDING HEAD (2)
12	HF5-0304-000	PLATE, SCANNER DRIVE
13	XB1-2300-407	SCREW, BH3X4 (S)
14	HH2-2748-000	WIRE, GROUNDING
15	XB4-7300-607	SCREW, TAP TIGHT, BINDING HEAD (2)

FIGURE 15 MultiPASS C5500 ADF, LOWER



NUM.	PART #	DESCRIPTION
15-1	HH2-2748-000	WIRE, GROUNDING
2	HH2-2745-000	CABLE, FLAT
3	HG5-1554-000	CONTACT SENSOR UNIT
4	HB1-2890-000	FRAME, ADF, LOWER
5	HS5-0235-000	GEAR, 19T
6	HB1-2878-000	ROLLER, DOCUMENT FEED
7	XD2-1100-402	RETAINING RING (E-TYPE)
8	HS1-1063-000	BUSHING
9	HB1-3289-000	ROLLER, DOCUMENT EJECT
10	HH7-2331-000	MOTOR, DOCUMENT FEED
11	XB4-7300-807	SCREW, TAP TIGHT, BINDING HEAD (2)
12	HF5-0304-000	PLATE, SCANNER DRIVE
13	XB1-2300-407	SCREW, BH3X4 (S) (3)

FIGURE 16 AUTO SHEET FEEDER & PCNT BOARD ASS'Y


See page 2-17 for the disassembly diagram of this unit.
1
3
2
See page 2-27 for the disassembly diagram of this unit.
See page 2-24 for the disassembly diagram of this unit.
See page 5-3 (FIGURE 16-a, 16-b)
4
5
1

NUM.	PART #	DESCRIPTION
16-1	XB6-7300-607	SCREW, TP, M3X6 (4)
2	HG5-1547-000	PCNT BOARD ASS'Y
3	HG5-1539-000	PRINT ASS'Y
4	HG5-1248-000	AUTO SHEET FEEDER ASS'Y
5	WT2-0317-000	CLIP, CABLE

FIGURE 17 CARRIAGE SECTION (1)



NUM.	PART #	DESCRIPTION
17-1	QB1-0501-020	ROLLER, IDLER
2	QB1-0502-000	BRACKET, IDLER
3	QB1-0503-000	SPRING, COIL
4	QB1-1229-000	CLIP, SHAFT
5	QB1-0972-000	GUIDE, CORNER
6	QB1-1045-000	PLATE, PAPER GUIDE
7	QB1-0497-020	HOLDER, CARRIAGE RIBBON CABLE
8	HG5-1544-000	CARRIAGE ASS'Y
9	XB5-6300-605	SCREW, TP, PH3X6
10	QB1-1995-000	SHAFT, CARRIAGE
11	QB1-0991-000	BELT, CARRIAGE
12	QB1-2250-020	HOLDER, BELT

FIGURE 18 CARRIAGE SECTION (2)



NUM.	PART #	DESCRIPTION
18-1	XA9-0613-000	NUT, SUS
2	HS5-2070-020	SPRING, HOOK END COIL
3	HB1-3282-000	ARM, CARRIAGE
4	HB1-3281-000	LEVER, FORMS THICKNESS
5	QB1-1282-000	SPRING, COIL
6	HG5-1138-000	CARRIAGE RIBBON CABLE UNIT
7	QB1-0984-000	GUIDE, RIBBON CABLE
8	HB1-3280-000	BASE, CARRIAGE
9	QB1-0985-000	PAD, CONTACT
10	QB1-0987-020	SPRING, COIL
11	QB1-1283-000	STOPPER
12	HB1-3283-000	LEVER, LOCKING
13	HB1-3284-000	COVER, LEVER
14	HG5-1545-000	CARTRIDGE HOLDER UNIT

FIGURE 19 MOTORS



NUM.	PART #	DESCRIPTION
19-1	HH7-2330-000	MOTOR, PULSE, CARRIAGE
2	XB1-2300-407	SCREW, BH3X4 (S) (4)
3	QH4-4222-000	MOTOR, PAPER FEED
4	QB1-0500-000	GEAR, SLOW DOWN

FIGURE 20 PAPER FEED SECTION (1)



NUM.	PART #	DESCRIPTION
20-1	QB1-0417-000	BUSHING
2	QB1-0423-000	SPRING, COIL
3	QB1-0622-000	WASHER, PLAIN
4	HG5-1130-000	PAPER FEED ROLLER ASS'Y
5	XA9-0613-000	NUT, SUS
6	QB1-0421-000	SPRING, COIL
7	QB1-0425-000	GEAR, TRANSMISSION
8	QB1-1275-000	ARM, TRANSMISSION
9	QB1-0422-000	BUSHING
10	HG5-1540-000	SPUR ASS'Y
11	QB1-1965-000	ROLLER, TRANSMISSION (2)
12	QB1-1278-000	SHAFT, ROLLER (2)
13	HG5-1542-000	PAPER EJECT ROLLER UNIT
14	HH7-2266-030	INK DETECTION UNIT
15	HB1-2773-000	FRAME, PLATEN
16	HH2-2729-020	CABLE W/CONNECTOR, 4P

FIGURE 21 PAPER FEED SECTION (2) & PURGE UNIT



NUM.	PART #	DESCRIPTION
21-1	XA9-0693-000	SCREW, BH (RED) M3X4 (2)
2	HB1-3276-000	FRAME, CARRIAGE GUIDE
3	QB1-0664-000	SPRING, COIL (6)
4	QB1-0409-000	PLATE, PRESSURE
5	XB4-7300-609	SCREW, TAP, BINDING HEAD, M3X6
6	QB1-0684-000	ROLLER, PRESSURE (5)
7	QB1-0467-000	SPRING, HOOK END COIL
8	QG5-1090-050	PURGE UNIT

FIGURE 22 PRINTER FRAME



NUM.	PART #	DESCRIPTION
22-1	QB1-0974-000	ARM, SENSOR
2	QB1-0414-000	HOOK, CARRIAGE
3	QB1-0415-000	SPRING, TORSION
4	QB1-0412-000	SPRING, TORSION
5	QB1-0973-000	ARM, PAPER SENSOR
6	QB1-2240-000	GUIDE, PRESSURE PLATE
7	HB1-2775-040	FRAME, PRINTER

FIGURE 23 SPURS



NUM.	PART #	DESCRIPTION
23-1	QG5-0368-000	CLEANER ROLLER UNIT (15)
2	QB1-1952-000	SPUR (15)
3	QB1-3044-000	SPUR SHAFT (15)

FIGURE 24 AUTO SHEET FEEDER (1)



NUM.	PART #	DESCRIPTION
24-1	QB1-2217-000	SUPPORT, PAPER
2	QB1-2921-000	GUIDE, PAPER
3	QG5-0960-000	PICK-UP ROLLER UNIT
4	QB1-0485-000	GEAR, TRANSMISSION
5	QB1-0480-000	GEAR, TRANSMISSION
6	QB1-2194-000	COIL SPRING HOOK END
7	QB1-0433-000	PAPER, GUIDE
8	QB1-2197-000	ROLLER, SLIP (2)
9	QB1-2198-000	RING, RUBBER, PICK-UP (2)
10	QB1-2924-000	RING, RUBBER
11	HB1-1598-020	PLATE, COVER SUPPORT

FIGURE 25 AUTO SHEET FEEDER (2)



NUM.	PART #	DESCRIPTION
25-1	QB1-2929-000	SEPARATOR, PAPER
2	QB1-2192-000	GEAR, CONTROL
3	QB1-0479-000	GEAR, TRANSMISSION
4	QB1-2212-000	GEAR, PICK-UP ROLLER
5	QB1-2195-000	PLATE, LEVER GUIDE
6	QB1-0483-000	GEAR, ONE WAY CLUTCH
7	QB1-0482-000	SPRING, ONE WAY CLUTCH
8	QB1-0484-000	GEAR, TRANSMISSION
9	QB1-2193-000	GEAR, CAM
10	XB4-7300-609	SCREW, TAP, BINDING HEAD, M3X6 (2)

FIGURE 26 AUTO SHEET FEEDER (3)



NUM.	PART #	DESCRIPTION
26-1	QF5-0351-000	PAPER LIFTING PLATE ASS'Y
2	QB1-2931-000	SPRING, COIL (2)
3	QB1-2922-000	FLAPPER, MEDIA SUPPORT (3)
4	QB1-1950-000	SHEET, MEDIA STOPPER (2)
5	HB1-2907-000	FRAME, ASF